








UL525 SERIES RIM EXIT DEVICE - REVERSIBLE INSTALLATION INSTRUCTIONS FOR LHR DOOR

10012 ZINS-R5019-45



UL525 SERIES RIM EXIT DEVICE - REVERSIBLE INSTALLATION INSTRUCTIONS FOR RHR DOOR

